

Let's Start Scenting!

What you'll need: ⌚ 5 minutes ✂ Matches

Step 1: Installation


Diffuser Placement

Aera creates scented air which circulates with the natural airflow in a room. Where Aera is placed can make a big difference in how well the fragrance covers a space.


Choose a spot in the room that's within reach of an electrical outlet and light a match.

Blow it out watch the smoke to see which direction it goes. It should move towards the area you want scented. If it doesn't, try another spot and repeat.

Tip: Doors often dictate how air flows in a room. Keep that in mind when testing and placing.




Once you've picked the perfect spot, plug in your diffuser and it will power on automatically.




Step 2: Operation

Capsules


Holding the capsule upright, **FIRST** remove the bottom plug, then the top plug.



For Aera Smart: insert the capsule into the diffuser opening and press it down a quarter inch or so. It will automatically lower and play.




For Aera Touch: press ⊕ eject to raise the capsule tray. Insert the capsule and press down a quarter inch. Press ⊕ eject again to lower and play.



Step 3: Operation


Diffuser Controls



- ⏻ **Power:** Turn diffuser on/off. (Located on back by plug.)
- ⊕ **Eject:** Ejects the capsule.
- ⊕ **Plus:** Increases strength.
- ⊖ **Minus:** Decreases strength.
- ⌚ **Session:** Starts session. Press multiple times to toggle settings between 2, 4, or 8 hours (See page 26).

Strength Setting: We recommend starting at level 5 and gradually raising or lowering until it's just how you like it (See page 23).

Recommended Strength by Room:



Aera Smart users: download the AeraForHome app to operate remotely, set schedules and more.

